

Supplies:

- 15' 3/4" x 3/4" square moulding
- 1 − 1x2x6 pine board
- 1 1x8x6 pine board
- Wood glue
- 1 1/4" wood screws
- 1 1/2" wood screws
- 1/4" x 3" hex bolt with wing nut

Cut List:

- 3 1x8 @ 24" (sign)
- 2 1x2 @ 17 ¾" (cleats)
- $3 \frac{3}{4}$ " moulding @ 59", on 2 pieces cut 10 degree miter at one end (stand legs)
- 1 1x2 @ 20" (ledge)



Step 1: Attach the cleats to the back of the sign boards using wood glue and countersunk 1 $\frac{1}{4}$ " wood screws.



Step 2: Connect the stand legs as per sketch above. Predrill hole for bolt and insert going through all 3 legs then tighten with wing nut.



Step 3: Attach sign ledge using wood glue and 1 ½" countersunk wood screws.